

# Contents

<b>Introduction</b> . . . . .	<b>1-1</b>
Important Information . . . . .	1-2
Viewing Total Blood Volume . . . . .	1-2
Viewing AC Data. . . . .	1-2
Alarms . . . . .	1-2
Maintaining Hemodynamic Stability in Pediatric Patients . . . . .	1-2
<b>Dual-Needle Therapeutic Plasma Exchange (TPE) Procedure</b> . . . . .	<b>2-1</b>
Equipment and Supplies . . . . .	2-2
Before You Start. . . . .	2-3
Configuration Options. . . . .	2-3
“Blood Prime” for Pediatric Patients . . . . .	2-5
Fluid Balance . . . . .	2-5
Calcium Replacement . . . . .	2-5
Net Additional Saline Returned to Patient . . . . .	2-7
Dual-Needle TPE Fluid Volumes . . . . .	2-7
Single-Needle TPE Fluid Volumes. . . . .	2-7
Volumes Processed During Rinseback . . . . .	2-7
Setting Up the Spectra System . . . . .	2-8
Installing the Filler. . . . .	2-8
Loading the Disposable Tubing Set . . . . .	2-8
Placing Tubing on the Front Panel . . . . .	2-8
Installing the Channel in the Filler. . . . .	2-10
Priming the Disposable Tubing Set . . . . .	2-12
Entering Patient Data . . . . .	2-15
Connecting the Patient . . . . .	2-18

Starting the Run . . . . .	2-19
Monitoring the Interface . . . . .	2-21
Managing Anticoagulant . . . . .	2-22
Keeping Track of AC in the Plasma. . . . .	2-23
Starting Rinseback . . . . .	2-24
Disconnecting the Patient . . . . .	2-25
Removing the Disposable Tubing Set . . . . .	2-25
Dual-Needle to Single-Needle Conversion. . . . .	2-26
Converting During Prime . . . . .	2-26
Converting During Run. . . . .	2-28
Helpful Hints and Recovery Procedures. . . . .	2-33
Viewing or Changing the Fluid Balance. . . . .	2-33
Changing Replacement Fluid. . . . .	2-33
Using Heparin As an Anticoagulant. . . . .	2-33
Leaving Patient Hypovolemic, Isovolemic or Hypervolemic by a Prescribed Volume . . . . .	2-34
Giving a Bolus of Replacement Fluid. . . . .	2-37
Administering Extra Replacement Fluid During Rinseback . . . . .	2-37
Red Blood Cell Accumulation and Manual Recovery. . . . .	2-38
Alarms and Troubleshooting . . . . .	2-40
Excessive plasma line contamination! . . . . .	2-40
NOTICE: Plasma line contamination alarm is not operational . . . . .	2-41
Plasma line contamination detected! . . . . .	2-42
RETURN FLOW TOO FAST!. . . . .	2-43
Spillover Recovery: Hematocrit increased. . . . .	2-44

**Single-Needle Therapeutic Plasma Exchange (TPE)**

**Procedure . . . . . 3-1**

Equipment and Supplies . . . . . 3-1

Before You Start . . . . . 3-2

Setting Up the Spectra System . . . . . 3-3

    Installing the Return Flow Controller . . . . . 3-3

    Installing the Filler . . . . . 3-3

Loading the Disposable Tubing Set . . . . . 3-3

    Placing Tubing on the Front Panel . . . . . 3-3

    Installing the Single-Needle Bag . . . . . 3-5

    Installing the Channel in the Filler . . . . . 3-6

Priming the Disposable Tubing Set . . . . . 3-9

Entering Patient Data . . . . . 3-12

Connecting the Patient . . . . . 3-13

Starting the Run . . . . . 3-13

    Monitoring the Interface . . . . . 3-16

    Managing Anticoagulant . . . . . 3-16

    Keeping Track of AC in the Plasma . . . . . 3-16

Starting Rinseback . . . . . 3-17

Disconnecting the Patient . . . . . 3-18

Removing the Disposable Tubing Set . . . . . 3-18

Single-Needle to Dual-Needle Backout Procedure . . . . . 3-18

Helpful Hints and Recovery Procedures . . . . . 3-19

    Fluid Balance . . . . . 3-19

Alarms and Troubleshooting . . . . . 3-19

**Platelet Depletion Procedure . . . . . 4-1**

Equipment and Supplies . . . . . 4-2

Before You Start . . . . . 4-3

    Deciding How Much Blood to Process . . . . . 4-3

    Collect Pump Flow Rate . . . . . 4-3

Fluid Balance . . . . . 4-3

“Blood Prime” for Pediatric Patients . . . . . 4-3

Spillovers . . . . . 4-3

Net Additional Saline Returned to Patient . . . . . 4-4

Platelet Depletion Fluid Volumes . . . . . 4-4

    Volumes Processed During Rinseback . . . . . 4-4

Setting Up the Spectra System . . . . . 4-5

    Installing the Filler . . . . . 4-5

Loading the Disposable Tubing Set . . . . . 4-5

    Placing Tubing on the Front Panel . . . . . 4-5

    Installing the Channel in the Filler . . . . . 4-7

Priming the Disposable Tubing Set . . . . . 4-9

Entering Patient Data . . . . . 4-12

Connecting the Patient . . . . . 4-14

Starting the Run . . . . . 4-15

    Spillovers . . . . . 4-17

Starting Rinseback . . . . . 4-18

Disconnecting the Patient . . . . . 4-19

Removing the Disposable Tubing Set . . . . . 4-19

Protocol for Spectra Version 6.1 and 7.0 Platelet  
Depletion . . . . . 4-20

    Platelet Depletion with Dual-Needle LRS or Standard  
    Dual-Needle ELP Disposable Tubing Set . . . . . 4-20

    Before You Start . . . . . 4-20

    Spillovers . . . . . 4-21

    Performing the Procedure . . . . . 4-21

**Red Blood Cell Exchange (RBCX) Procedure . 5-1**

Equipment and Supplies . . . . . 5-2

Before You Start . . . . . 5-3

    Determining Total Blood Volume . . . . . 5-3

    Entering Data . . . . . 5-3

    “Blood Prime” for Pediatric Patients . . . . . 5-3

    RBCX Fluid Volumes . . . . . 5-3

Calculating the Amount of Replacement Blood Needed . . 5-4

    Ending this Operation . . . . . 5-6

Setting Up the Spectra System . . . . . 5-7

    Installing the Filler . . . . . 5-7

Loading the Disposable Tubing Set . . . . . 5-7

    Placing Tubing on the Front Panel . . . . . 5-7

    Installing the Channel in the Filler . . . . . 5-9

Priming the Disposable Tubing Set . . . . . 5-10

Entering Patient Data . . . . . 5-13

Connecting the Patient . . . . . 5-16

Starting the Run . . . . . 5-17

Skipping Rinseback and Disconnecting the Patient . . . . . 5-19

Removing the Disposable Tubing Set . . . . . 5-20

Red Blood Cell Depletion . . . . . 5-21

Helpful Hints . . . . . 5-21

    Calculating the desired FCR from a known  
    Hemoglobin S (Hgb S) level . . . . . 5-21

Alarms and Troubleshooting . . . . . 5-22

    Invalid replacement fluid volume. Decrease end  
    hematocrit . . . . . 5-22

    Invalid replacement fluid volume. Decrease FCR . . . 5-23

    Invalid replacement fluid volume. Increase end  
    hematocrit . . . . . 5-23

    Invalid replacement fluid volume. Increase FCR . . . 5-23

    Invalid process time. Decrease replacement fluid  
    volume . . . . . 5-24

Invalid process time. Increase replacement fluid  
volume . . . . . 5-24

**White Blood Cell (WBC) Depletion  
Procedure . . . . . 6-1**

    MNC vs. PMN . . . . . 6-1

Equipment and Supplies . . . . . 6-2

    MNC Procedures Only . . . . . 6-2

    PMN Procedures Only . . . . . 6-2

Before You Start . . . . . 6-3

    “Blood Prime” for Pediatric Patients . . . . . 6-3

    Configuration Options . . . . . 6-3

    Fluid Balance . . . . . 6-4

    Volume to be Processed . . . . . 6-5

    Collect Pump Flow Rate . . . . . 6-5

    Sedimenting Agents . . . . . 6-5

    Net Additional Saline Returned to Patient . . . . . 6-5

    WBC Depletion Fluid Volumes . . . . . 6-6

    Volumes Processed During Rinseback . . . . . 6-6

Setting Up the Spectra System . . . . . 6-7

    Installing the Filler . . . . . 6-7

Loading the Disposable Tubing Set . . . . . 6-7

    Placing Tubing on the Front Panel . . . . . 6-7

    Installing the Channel in the Filler . . . . . 6-9

Priming the Disposable Tubing Set . . . . . 6-10

Entering Patient Data . . . . . 6-14

Connecting the Patient . . . . . 6-16

Starting the Run . . . . . 6-17

    Quick Start . . . . . 6-17

    Monitoring the Interface . . . . . 6-18

Changing the Collect Pump Flow Rate . . . . . 6-19  
 Continuing the Run. . . . . 6-19  
 Ending the Run . . . . . 6-19  
 Starting Rinseback. . . . . 6-21  
 Disconnecting the Patient . . . . . 6-22  
 Removing the Disposable Tubing Set . . . . . 6-22  
 Helpful Hints and Recovery Procedures . . . . . 6-23  
     Establishing the Optimum Interface . . . . . 6-23  
     Correcting WBC Procedure Type . . . . . 6-24

**Lymphoplasma Exchange (LPE) Procedure . . . 7-1**

Equipment and Supplies . . . . . 7-2  
 Before You Start . . . . . 7-3  
     “Blood Prime” for Pediatric Patients . . . . . 7-3  
     Net Additional Saline Returned to Patient. . . . . 7-3  
     LPE Fluid Volumes . . . . . 7-3  
     Volumes Processed During Rinseback . . . . . 7-3  
 Calculating Remove and Replacement Fluid Volumes. . . . . 7-4  
 Setting Up the Spectra System. . . . . 7-4  
     Installing the Filler. . . . . 7-4  
 Loading the Disposable Tubing Set . . . . . 7-5  
     Placing Tubing on the Front Panel . . . . . 7-5  
     Installing the 4-Liter Waste Bag. . . . . 7-5  
     Installing the Channel in the Filler. . . . . 7-5  
 Priming the Disposable Tubing Set . . . . . 7-6  
 Entering Patient Data . . . . . 7-7  
 Connecting the Replacement Fluid . . . . . 7-8  
 Connecting the Patient . . . . . 7-9  
 Starting the Run . . . . . 7-10  
     Quick Start . . . . . 7-11  
     Using the COBE Spectra WBC Colorgram . . . . . 7-11

Continuing the Run. . . . . 7-12  
 Setting Target End Results. . . . . 7-14  
 Starting Rinseback. . . . . 7-14  
 Disconnecting the Patient . . . . . 7-14  
 Removing the Disposable Tubing Set . . . . . 7-14

**Index . . . . . i-1**